

Bosch | Code 2608630037 | Sku 45905

T 119 B Basic for Wood Jigsaw Blade

Short Description

Bosch T 119 B Basic for Wood HCS jigsaw blades for straight cuts in softwood and non-abrasive wood-based materials.

Technical Specifications

Brand	Bosch
Model	T119B
Mfr part no.	2608630037
SKU	45905
Type	Jigsaw blade
Total Length	92 mm
Toothed Length	67 mm
Tooth Pitch	1.9–2.3 mm
Cutting Capacity	2–15 mm
Cut Type	Straight cuts
Material	HCS high-carbon steel
Tooth Design	Wavy-set, milled
Arbor Size	T-shank
Applications Materials	Softwood, plywood, chipboard, wood core plywood and fibreboard
Pack Quantity	5 blades
Packaging Type	Blister

Description

The Bosch T 119 B Basic for Wood jigsaw blade features a fine progressive tooth pitch suitable for straight cuts in softwood, plywood, chipboard, wood core plywood and fibreboard.

Key Features

- High-carbon steel HCS blade
- Milled, wavy-set tooth design
- Fine progressive tooth pitch
- Fits jigsaws with T-shank blade holders

Applications

- Straight cutting in softwood
- Cutting plywood
- Cutting chipboard
- Cutting wood core plywood
- Cutting fibreboard

- Cutting non-abrasive wood-based materials

What's Included

- 5 x Bosch T 119 B Basic for Wood jigsaw blades