

Kärcher | Code 1.324-304.0 | Sku 817767

K 4 Power Control Flex Home



Short Description

Electric Kärcher high-pressure washer with Power Control trigger gun, PremiumFlex high-pressure hose and Home Kit for cleaning patios, garden furniture, vehicles and other outdoor surfaces.

Technical Specifications

Brand	Kärcher
Mfr part no.	1.324-304.0
SKU	817767
Type	Electric high-pressure washer
Dimensions	405 × 306 × 584 mm (L × W × H)
Weight	12.2 kg without accessories; 18.1 kg including packaging
Pressure	20–130 bar / 2–13 MPa
Flow Rate	Maximum 420 l/h
Area Performance	30 m ² /h
Maximum Inlet Temperature	40 °C
High Pressure Hose	8 m PremiumFlex high-pressure hose
Power Cable Length	5 m
Motor	Water-cooled motor
Power	1.8 kW rated input power
Voltage	230–240 V
Frequency	50 Hz
Colour	Yellow
Ean	4066529126948

Description

The Kärcher K 4 Power Control Flex Home is for moderate dirt on patios, garden furniture, bicycles, motorcycles and small cars. It supports Kärcher Home & Garden app guidance and Plug 'n' Clean detergent application, and the included Home Kit adds a T 5 surface cleaner and 1 litre of stone and façade cleaner.

Key Features

- G 160 Q Power Control trigger gun with pressure display
- Adjustable pressure through the Vario Power spray lance
- Kärcher Home & Garden app with application guidance
- Plug 'n' Clean detergent system
- Telescopic handle
- Integrated water filter
- Device-side Quick Connect connection

Applications

- Bicycles
- Motorcycles and scooters
- Small cars
- Garden tools and equipment
- Garden, terrace and balcony furniture
- Patios and outdoor areas around the home
- Fences and paving stones

What's Included

- Kärcher K 4 Power Control Flex Home pressure washer
- G 160 Q Power Control high-pressure gun
- Vario Power spray lance
- Dirt blaster
- 8 m PremiumFlex high-pressure hose
- T 5 surface cleaner
- 1 litre stone and façade cleaner, 3-in-1
- A3/4-inch garden hose adapter