

Kärcher | Code 1.676-362.0 | Sku 818694

K 3 eco!Booster Car & Home



Short Description

Electric Kärcher K 3 pressure washer kit with eco!Booster, car-cleaning accessories, home-cleaning accessories, and a 6 m high-pressure hose.

Technical Specifications

Brand	Kärcher
Mfr part no.	1.676-362.0
SKU	818694
Type	Electric high-pressure washer
Dimensions	242 x 285 x 805 mm (L x W x H)
Weight	4.3 kg without accessories
Pressure	20 to maximum 120 bar / 2 to maximum 12 MPa
Flow Rate	Maximum 380 l/h
Detergent Flow Rate	0.3 l/min
Area Performance	25 m ² /h
High Pressure Hose	6 m
Power Cable	5 m
Power	1.4 kW rated input power
Voltage	220-240 V
Phase	Single phase
Frequency	50-60 Hz
Current Consumption	6 A
Water Feed Pressure	Maximum 1.2 MPa
Water Feed Temperature	Maximum 40 °C
Maximum Suction Height	0.5 m

Minimum Input Water Volume	8 l/min
High Pressure Gun Recoil Force	12 N
Vibration	1.7 m/s ² hand-arm vibration; uncertainty K 0.7 m/s ²
Noise Level	74 dB(A) sound pressure level; 90 dB(A) sound power level
Eco Booster Performance	Up to 50% higher cleaning performance compared with the Kärcher standard flat jet
Colour	Yellow
Protection Type	IPX5
Protection Class	Class II
Equipment	Quick Connect on machine; detergent application via suction hose; integrated water filter

Description

The Kärcher K 3 eco!Booster Car & Home is a domestic high-pressure washer designed for cleaning vehicles, patios, garden furniture, tools, outdoor surfaces, and small areas around the home. The kit includes an eco!Booster spray lance for delicate surfaces, a dirt blaster for stubborn dirt, a T 1 surface cleaner, wash brush, foam jet, and detergents.

Key Features

- eco!Booster spray lance for delicate surfaces
- Dirt blaster for stubborn dirt
- Home kit with T 1 surface cleaner and Patio & Deck detergent
- Car kit with wash brush, foam jet, and car shampoo
- Integrated water filter
- Quick Connect connection on the machine
- Detergent application via suction hose
- Large transport wheels and integrated storage

Applications

- Cleaning cars
- Cleaning motorcycles and scooters
- Cleaning bicycles, e-bikes, and mountain bikes
- Cleaning patios
- Cleaning garden furniture
- Cleaning garden machines and tools
- Cleaning driveways and outdoor surfaces
- General cleaning around the home and garden

What's Included

- Kärcher K 3 eco!Booster Car & Home pressure washer
- T 1 surface cleaner

-
- Patio & Deck detergent, 0.5 l
 - Wash brush
 - Foam jet
 - Car Shampoo, 0.5 l
 - eco!Booster spray lance
 - Dirt blaster
 - High-pressure hose, 6 m
 - Garden hose adapter A3/4 inch